



3307 Industrial 25th Street
Fort Pierce, FL 34946
Phone: 772-429-0045
Fax: 772-429-0170

UltraSonic Cleaner

Operating Instructions

Model HS-2Q

1. Plug into 120 Vac 50/60 Hz
2. Pour two ounces of UltraSonic cleaning solution into the tank
3. Fill the rest of the tank with water up to the groove (1 inch below the top)
4. Set timer for desired time or "ON" for continuous operation
5. If heat is desired, switch the black switch to "ON"

WARNING

- Do not operate without water
- Do not over fill
- Do not clean with jewelry laying on the bottom of the tank
- Do not fill while unit is plugged into ac power
- Do not immerse the unit in water
- Do not use the unit if the cord or plug are damaged
- Keep unit away from heated surfaces and place on flat surface only
- Do not touch unit if you are wet or touching water

Do not use in the following jewelry

Amber, Apatite, Cat's Eye (Chrysoberyl), Coral, Diopside, Emerald (Beryl), Jade (Jadeite and Nephrite) Kunzite (Spodumene), Lapis Lazuli, Malachite, Opal, Pearls, Peridot, Tanzanite, Topaz, or Turquoise
Dymond, Inc. shall not be held legally liable or responsible for any damage caused and Warranty will be Void if the unit is opened or for any misuse.